

DUCTLESS MINI-SPLIT SYSTEM AIR CONDITIONER/HEAT PUMP

SLIM CEILING CASSETTE MODELS



CAB/CYB Series

CAB: Cooling-Only Version

CYB: Cooling and Heating Version

Inverter+ and Inverter++ Models

24,000 - 48,000 BTU/hr



Installation Manual

IMPORTANT NOTICE:



Please read this manual carefully before installing or operating your new air conditioning system. Be sure to save this manual for future reference.



Table of Contents


Installation Manual

1	Accessories.....	04
2	Safety Precautions.....	05
3	Installation Overview.....	06




4	Indoor Unit Installation.....	07
	a. Indoor Unit Parts.....	07
	b. Indoor Unit Installation Instructions.....	08

5	Outdoor Unit Installation.....	11
	a. Outdoor Unit Installation Instructions.....	11
	b. Outdoor Unit Types and Specifications.....	12
	c. Notes on Drilling Wall Hole.....	13





6	Drainpipe Installation.....	14
----------	-----------------------------	----



7 Refrigerant Piping Connection.....16

A. Notes on Pipe Length and Elevation.....16

B. Refrigerant Piping Connection Instructions.....17



8 Wiring.....19

a. Outdoor Unit Wiring.....19

b. Indoor Unit Wiring.....20


c. Power Specifications.....21

d. Wiring Diagram.....22

9 Air Evacuation.....23

a. Evacuation Instructions.....23

b. Note on Adding Refrigerant.....24

















10 Panel Installation.....25

11 Test Run.....27

Accessories

1

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail.

	Name	Shape	Quantity
Indoor Unit Installation	Installation Paper Template (some models)		1
Refrigeration Fittings	Soundproof/Insulation Sheath (some models)		1
Drainpipe Fittings	Outlet Pipe Sheath (some models)		1
	Outlet Pipe Clasp (some models)		1
	Drain Joint (some models)		1
	Seal Ring (some models)		1
Installation Accessory (field supplied hardware, Not Included)	Ceiling Hook		4
	Suspension Bolt		4
	Orifice Tube (some units)		1
EMC Magnetic Ring (some models)	Magnetic Ring (wrap the electric wires P & Q & E around the Magnetic Ring twice)		1
Remote Controller & Its Holder (some models)	Remote Controller		1
	Fixing Screw for Remote Controller Holder ST2.9 x 10		2
	Remote Controller Holder		1
	Dry Battery AAA		2
	Remote Controller Illustration		1
	Owner's Manual		1
	Installation Manual		1

Read Safety Precautions Prior to Installation

Improper installation due to negligence of instructions may result in serious damage or injury. The magnitude of potential damages or injuries is classified as either a WARNING or a CAUTION.



WARNING

Failure to observe a warning may result in death. The appliance must be installed in accordance with all national regulations.



CAUTION

Failure to observe a caution may result in personal injury or equipment damage.

WARNING

- Read the Safety Precautions carefully prior to installation.
- In certain functional environments, such as kitchens, server rooms, etc., the use of specially designed air-conditioning units is highly recommended. This is intended as a comfort cooling system.
- Only trained and certified technicians should install, repair, and service this air conditioning unit.
- Attempts to self-install can lead to inefficient performance, and risk of equipment damage over time.
- Strictly follow the installation instructions set forth in this manual.
- Improper installation may result in electrical shock, short circuit, leaks, fire, or other damage to the equipment.
- Before you install the unit, consider strong winds, typhoons and earthquakes, which might affect your unit, and locate it accordingly. Failure to do so could cause the equipment to fail.
- After installation, ensure that there are no refrigerant leaks, and that the unit is operating properly. Refrigerant is both toxic and flammable, and poses a serious health and safety risk.


Note about Fluorinated Gasses

1. This air-conditioning unit contains fluorinated gasses. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself.
2. Installation, service, maintenance, and repair of this unit must be performed by a certified HVAC technician.
3. Product uninstallation and recycling must be performed by a certified HVAC technician.
4. If the system has a leak-detection feature installed, it must be checked for leaks at least every 12 months.
5. When the unit is being checked for leaks, proper logging and record-keeping of all checks is strongly recommended.

Installation Overview

3

INSTALLATION ORDER



Indoor Unit Parts




Fig. 4.1

Safety Precautions

WARNING

- Securely install the indoor unit on a structure that can sustain its weight. If the structure is too weak, the unit may fall causing personal injury, unit and property damage, or death.
- Install the indoor unit at a height of more than 2.5m (8') above the floor.
- **DO NOT** install the indoor unit in the bathroom or laundry room, as excessive moisture can short the unit, and corrode the wiring.

CAUTION

- Install the indoor and outdoor units, cables, and wires at least 1m (3.2') from televisions or radios, to prevent static or image distortion. Depending on the appliances, a 1m (3.2') distance may not be sufficient.
- If the indoor unit is installed on a metal part of the building, it must be electrically grounded.

Indoor Unit Installation Instructions

NOTE: Panel installation should be done after piping and wiring.

Step 1: Select Installation Location

The indoor unit should be installed in a location that meets the following requirements:

- ☑ The unit is at least 1m (39") from the nearest wall.
- ☑ There is enough room for installation and maintenance.
- ☑ There is enough room for the connecting pipe and drainpipe.
- ☑ The ceiling is horizontal, and its structure can sustain the weight of the indoor unit.
- ☑ The air inlet and outlet are not impeded.
- ☑ The airflow can fill the entire room.
- ☑ There is no direct radiation from heaters.

! CAUTION

DO NOT install the unit in the following locations:

- ⊘ In areas with oil drilling or fracking
- ⊘ In coastal areas with high air salinity
- ⊘ In areas with caustic gases in the air, such as near hot springs
- ⊘ In areas with power fluctuations, such as factories
- ⊘ In enclosed spaces, such as cabinets
- ⊘ In kitchens that use natural gas
- ⊘ In areas with strong electromagnetic waves
- ⊘ In areas that store flammable materials or gas
- ⊘ In rooms with high humidity, such as bathrooms or laundry rooms

RECOMMENDED DISTANCES BETWEEN THE INDOOR UNIT AND THE CEILING

The distance between the mounted indoor unit and the internal ceiling should meet the following specifications. (See Fig. 4.2)




Fig. 4.2

Table 4.1: Distance from ceiling relative to height of indoor unit

MODEL	Length of A (mm/inch)	Length of H (mm/inch)
18	205/8	> 235/9.3
24	205/8	> 235/9.3
30	205/8	> 235/9.3
30-48	245/9.6	> 275/10.8
48-60	287/11.3	> 317/12.5

Step 2: Hang Indoor Unit.

1. Use the included paper template to cut a rectangular hole into the ceiling, leaving at least 1m (39") on all sides. The hole will be 88x88cm (34.5x34.5") big. Be sure to mark the areas where the ceiling hook holes will be drilled.

Refrigerant Piping side





Fig. 4.3

! CAUTION

The unit body should align perfectly with the hole. Ensure that the unit and the hole are the same size before moving on.

2. Drill 4 holes 5cm (2") deep at the ceiling hook positions in the internal ceiling. Be sure to hold the drill at a 90° angle to the ceiling.
3. Using a hammer, insert the ceiling hooks into the pre-drilled holes. Secure the bolt using the included washers and nuts.
4. Install the four suspension bolts (See Fig. 4.4).




Fig. 4.4

5. Mount the indoor unit. You will need two people to lift and secure it. Insert suspension bolts into the unit's hanging holes. Fasten them using the included washers and nuts (See Fig. 4.5).




Fig. 4.5

NOTE: The bottom of the unit should be 10 - 18mm (0.4-0.7") higher than the ceiling board. Generally, L (indicated in Fig. 4.6) should be half the length of the suspension bolt, or long enough to prevent the nuts from coming off.




Fig. 4.6

! CAUTION

Ensure that the unit is completely level. Improper installation can cause the drain pipe to back up into the unit or lead to water leakage.

NOTE: Ensure that the indoor unit is level. The unit is equipped with a built-in drain pump and float switch. If the unit is tilted against the direction of condensate flows (the drainpipe side is raised), the float switch may malfunction, and cause water to leak.




Fig. 4.7

NOTE FOR NEW HOME INSTALLATION

When installing the unit in a new home, the ceiling hooks can be embedded in advance. Make sure that the hooks do not come loose due to concrete shrinkage. After installing the indoor unit, fasten the installation paper template onto the unit with bolts (M6X12), to determine in advance the dimension and position of the opening on the ceiling. Follow the instructions above for the remainder of the installation.




Fig. 4.8

Outdoor Unit Installation

5

Outdoor Unit Installation Instructions

Step 1: Select Installation Location.

The outdoor unit should be installed in a location that meets the following requirements:

- ☑ The location is as close to the indoor unit as possible.
- ☑ Ensure that there is enough room for installation and maintenance.
- ☑ The air inlet and outlet are not obstructed, or exposed to strong wind.
- ☑ The location of the unit will not be subject to snowdrifts, accumulation of leaves, or other seasonal debris. If possible, provide an awning for the unit. Ensure the awning does not obstruct airflow.
- ☑ The installation area is dry and well ventilated.
- ☑ There must be enough room to install the connecting pipes and cables, and to access them for maintenance.

- ☑ The area must be free of combustible gases and chemicals.
- ☑ The pipe length between the outdoor and indoor unit may not exceed the maximum allowable pipe length.
- ☑ If possible, DO NOT install the unit where it is exposed to direct sunshine.
- ☑ If possible, make sure the unit is located far away from the property of neighbors, so that the unit noise will not cause disturbances
- ☑ If the location is exposed to strong winds (for example: near a seaside), the unit must be placed against the wall to shelter it from the wind. If necessary, use an awning. (See Fig. 5.1 & 5.2)
- ☑ Install the indoor and outdoor units, cables, and wires at least 1 meter from televisions or radios, to prevent static or image distortion. Depending on the radio waves, a 1 meter distance may not be enough to eliminate all interference.




Fig. 5.1




Fig. 5.2

Min. Front Clearance
200 cm / 78" to the wall

Step 2: Install outdoor unit.

Fix the outdoor unit with anchor bolts (M10)




Fig. 5.3

! CAUTION

- Be sure to remove any obstacles that may block air circulation.
- Refer to Length Specifications to ensure there is enough room for installation and maintenance.

Split Type Outdoor Unit

(Refer to Fig 5.4, 5.5, 5.6, 5.10 and Table 5.1)






Table 5.1: Length Specifications of Split Type Outdoor Unit (unit: mm/inch)

Outdoor Unit Dimensions	Mounting Dimensions	
	W x H x D	Distance A

YN009GMFI22RPD:

770x555x300 (30.3x21.9x11.8)	549 (21.6)	325 (12.8)
------------------------------	------------	------------

YN012GMFI22RPD:

800x554x333 (31.5x21.8x13.1)	514 (20.24)	340 (13.39)
------------------------------	-------------	-------------

YN018GMFI22RPD:

845x702x363 (33.27x27.6x14.3)	540 (21.26)	350 (13.8)
-------------------------------	-------------	------------

YN024GMFI22RPD:

946x810x410 (37.24x31.9x16.14)	673 (26.5)	403 (15.87)
--------------------------------	------------	-------------

YN036GMFI17RUD:

946x810x410 (37.24x31.9x16.14)	673 (26.5)	403 (15.87)
--------------------------------	------------	-------------

YN048GMFI17RUD:

952x1333x415 (37.5x52.5x16.34)	634 (24.96)	404 (15.9)
--------------------------------	-------------	------------

NOTE: The minimum distance between the outdoor unit and walls described in the installation guide does not apply to airtight rooms. Be sure to keep the unit unobstructed in at least two of the three dimensions (M, N, P). (See Fig. 5.10)




Fig. 5.10

Notes On Drilling Wall Hole

You must drill a hole in the wall for the refrigerant piping, and the signal cable that will connect the indoor and outdoor units.

1. Determine the location of the wall hole based on the location of the outdoor unit.
2. Using a 65-mm (2.5") core drill, drill a hole into the wall.

NOTE: When drilling the wall hole, be sure to avoid wires, plumbing, and other sensitive components.

3. Place the protective wall cuff into the hole. This protects the edges of the hole and will help seal it when you finish the installation process.

Drain Joint Installation

Before bolting the outdoor unit into place, you must install the drain joint at the bottom of the unit. (See Fig. 5.11)

1. Fit the rubber seal onto the end of the drain joint that will connect to the outdoor unit.
2. Insert the drain joint into the hole in the base pan of the unit.
3. Rotate the drain joint 90° until it clicks into place facing the front of the unit.
4. Connect a drain hose extension (not included) to the drain joint, to redirect water from the unit during heating mode.

NOTE: Make sure the water drains to a safe location where it will not cause water damage or a slipping hazard.




Fig. 5.11

Drainpipe Installation

6

The drainpipe is used to drain water from the unit. Improper installation may cause unit and property damage.

CAUTION

- Insulate all piping to prevent condensation, which could lead to water damage.
- If the drainpipe is bent, or installed incorrectly, water may leak and cause a water-level switch malfunction.
- In HEAT mode, the outdoor unit will discharge water. Ensure that the drain hose is placed in an appropriate area, to avoid water damage and slippage due to frozen drain water.
- **DO NOT** pull the drainpipe forcefully, as this could cause it to disconnect or be damaged.

NOTE ON PURCHASING PIPES

This installation requires a polyethylene tube (outside diameter = 3.7-3.9cm, inside diameter = 3.2cm), which can be obtained at your local hardware store, or from your dealer.

Indoor Drainpipe Installation

Install the drainpipe as illustrated in Figure 6.2.

1. Cover the drainpipe with heat insulation, to prevent condensation and leakage.
2. Attach the mouth of the drain hose to the unit's outlet pipe. Sheath the mouth of the hose, and clip it firmly with a pipe clamp. (Fig 6.1)




Fig. 6.1




Fig. 6.2

NOTE ON DRAINPIPE INSTALLATION

- When using an extended drainpipe, tighten the indoor connection with an additional protection tube. This prevents it from pulling loose.
- The drainpipe should slope downward at a gradient of at least 1/100, to prevent water from flowing back into the air conditioner.
- To prevent the pipe from sagging, space hanging wires every 1-1.5m (40-59").
- If the outlet of the drainpipe is higher than the body's pump joint, provide a lift pipe for the exhaust outlet of the indoor unit. The lift pipe must be installed no higher than 75cm (29.5") from the ceiling board. The distance between the unit and the lift pipe must be less than 30cm (11.8"). Incorrect installation could cause water to flow back into the unit and flood.
- To prevent air bubbles, keep the drain hose level, or slightly tilted up (<75mm / 3").




Fig. 6.3

NOTE: When connecting multiple drainpipes, install the pipes as shown in Fig 6.4.




Fig. 6.4

- Using a 65-mm (2.5") core drill, drill a hole into the wall. Make sure that the hole is drilled at a slightly downward angle, so that the outdoor end of the hole is lower than the indoor end by about 12mm (0.5"). This will ensure proper water drainage (See Fig. 6.5). Place the protective wall cuff into the hole. This protects the edges of the hole and will help seal it once the installation process is completed.




Fig. 6.5

NOTE: When drilling the wall hole, make sure to avoid wires, plumbing, and other sensitive components.

- Pass the drain hose through the wall hole. Make sure the water drains to a safe location where it will not cause water damage, or a slipping hazard.

NOTE: The drainpipe outlet should be at least 5cm (1.9") above the ground. If it touches the ground, the unit may become blocked and malfunction. If you discharge the water directly into a sewer, make sure that the drain has a U or S pipe, to catch odors that might otherwise come back into the house.

Refrigerant Piping Connection

Safety Precautions

WARNING

- All field piping must be completed by a licensed technician, and must comply with all local and national regulations.
- When the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration in the room from exceeding the safety limit, in the event of refrigerant leakage. If the refrigerant leaks, and its concentration exceeds its proper limit, hazards due to lack of oxygen may result.
- When installing the refrigeration system, ensure that air, dust, moisture, or foreign substances do not enter the refrigerant circuit. Contamination in the system may cause poor operating capacity, high pressure in the refrigeration cycle, explosion, or injury.
- Ventilate the area immediately if there is refrigerant leakage during the installation. Leaked refrigerant gas is both toxic and flammable. Ensure there is no refrigerant leakage after completing the installation work.

Notes On Pipe Length and Elevation

Ensure that the length of the refrigerant pipe, the number of bends, and the drop height between the indoor and outdoor units meets the requirements shown in Table 7.1:

Table 7.1: The Maximum Length And Drop Height Based on Models. (Unit: m/ft.)

Type of Model	Capacity (Btu/h)	Length of Piping	Maximum Drop Height
North America, Australia and the Europe Inverter Split Type	<15K	25/82	10/33
	≥15K - <24K	30/100	20/66
	≥24K - <36K	50/164	25/82
	≥36K - ≤60K	65/213	30/98.4
Other Split Type	12K	15/49	8/26
	18K-24K	25/82	15/49
	30K-36K	30/100	20/66
	42K-60K	50/164	30/100

Refrigerant Piping Connection Instructions

! CAUTION

- The branching pipe must be installed horizontally. An angle of more than 10° may cause malfunctions.
- **DO NOT** install the connecting pipe until both the indoor and outdoor units have been installed.
- Insulate both the gas and liquid piping to prevent water leakage.

Step 1: Cut pipes

When preparing refrigerant pipes, take extra care to cut and flare them properly. This will ensure efficient operation, and minimize the need for future maintenance.

1. Measure the distance between the indoor and outdoor units.
2. Using a pipe cutter, cut the pipe a bit longer than the measured distance.

! CAUTION

DO NOT deform pipe while cutting. Be extra careful not to damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.

1. Ensure that the pipe is cut at a perfect 90° angle. Refer to Fig. 7.2 for examples of bad cuts.




Fig. 7.2

Step 2: Remove Burrs.

Burrs can affect the air-tight seal of the refrigerant piping connection. They must be completely removed.

1. Hold the pipe at a downward angle, to prevent burrs from falling into the pipe.
2. Using a reamer or deburring tool, remove all burrs from the cut section of the pipe.




Fig. 7.3

Step 3: Flare Pipe Ends

Proper flaring is essential in achieving an airtight seal.

1. After removing burrs from cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
2. Sheath the pipe with insulating material.
3. Place flare nuts on both ends of pipe. Make sure they are facing the correct direction, because they cannot be put on or have their direction changed after flaring. See Fig. 7.4




Fig. 7.4

4. Remove PVC tape from pipe ends when ready to perform flaring work.
5. Clamp flare form onto the end of the pipe. The end of the pipe must extend beyond the flare form.




Fig. 7.5

- Place flaring tool onto the form.
- Turn the handle of the flaring tool clockwise until the pipe is fully flared. Flare the pipe in accordance with the dimensions shown in table 7.5.




Fig. 7.8

Table 7.5: PIPING EXTENSION BEYOND FLARE FORM

Pipe Gauge	Tightening Torque	Flare Dimension (A) (Unit: mm/Inch)		Flare Shape
		Min.	Max.	
Ø 1/4	14.2-17.2 N.m (10.5 - 12.5 Lb.Ft.)	8.3/0.3	8.3/0.3	
Ø 3/8	32.7-39.9 N.m (24 - 30 Lb.Ft.)	12.4/0.5	12.4/0.5	
Ø 1/2	49.5-60.3 N.m (36 - 45 Lb.Ft.)	15.4/0.6	15.8/0.6	
Ø 5/8	61.8-75.4 N.m (45 - 52 Lb.Ft.)	18.6/0.7	19/0.74	
Ø 3/4	97.2-118.6 N.m (72 - 88 Lb.Ft.)	22.9/0.9	23.3/0.9	
Ø 7/8	109.5-133.7 N.m (81 - 102 Lb.Ft.)	27/1.06	27.3/1.07	




Fig. 7.6

- Remove the flaring tool and flare form, then inspect the end of the pipe for cracks and for even flaring.

Step 4: Connect Pipes

Connect the copper pipes to the indoor unit first, then connect it to the outdoor unit. You should first connect the low-pressure pipe, then the high-pressure pipe.

- When connecting the flare nuts, apply a thin coat of refrigeration oil to the flared ends of the pipes.
- Align the center of the two pipes that you will connect.




Fig. 7.7

- Tighten the flare nut as tightly as possible by hand.
- Using a spanner, grip the nut on the unit tubing.
- While firmly gripping the nut, use a torque wrench to tighten the flare nut, according to the torque values in Table 7.5.

NOTE: Use both a spanner and a torque wrench when connecting or disconnecting pipes to/from the unit.


CAUTION

- Be sure to wrap insulation around the piping. Direct contact with the bare piping may result in burns or frostbite.
- Make sure the pipe is properly connected.
- Over tightening may damage the bell mouth, and under tightening may lead to leakage.

NOTE ON MINIMUM BEND RADIUS

Carefully bend the tubing in the middle according to the diagram below. **DO NOT** bend the tubing more than 90°, or more than 3 times.

Bend the pipe using thumbs



min-radius 10cm (3.9")

Fig. 7.9

- After connecting the copper pipes to the indoor unit, wrap the power cable, signal cable, and the piping together with binding tape.

NOTE: **DO NOT** intertwine signal cable with other wires. While bundling these items together, do not intertwine or cross the signal cable with any other wiring.

- Thread this pipeline through the wall and connect it to the outdoor unit.
- Insulate all the piping, including the valves of the outdoor unit.
- Open the stop valves of the outdoor unit to start the flow of the refrigerant between the indoor and outdoor unit.

CAUTION

Check to make sure there is no refrigerant leak after completing the installation work. If there is a refrigerant leak, ventilate the area immediately and evacuate the system (refer to the Air Evacuation section of this manual).

Safety Precautions

WARNING

- Disconnect the power supply before working on the unit.
- All wiring must be performed according to all relevant local and national regulations.
- Wiring must be done by a qualified technician. Improper connections may cause electrical malfunction, injury, or fire.
- An independent circuit and single outlet must be used for this unit. **DO NOT** plug another appliance or charger into the same outlet. If it cannot handle the load or there is a defect in the wiring, it can lead to shock, fire, and unit and property damage.
- Connect the power cable to the terminals and fasten it with a clamp. An unsecure connection may cause fire.
- Make sure that all wiring is done correctly and that the control board cover is properly installed. Failure to do so can cause overheating at the connection points, fire, and electrical shock.
- Ensure that main power supply connection is made through a switch that disconnects all poles, with a contact gap of at least 3mm (0.12").
- **DO NOT** modify the length of the power cord, or use an extension cord.

CAUTION

- Connect the outdoor wires before connecting the indoor wires.
- Make sure you ground the unit. The grounding wire should be located away from gas pipes, water pipes, lightning rods, telephone or other grounding wires. Improper grounding may cause electrical shock.
- **DO NOT** connect the unit to the power source until all wiring and piping is completed.
- Make sure that you do not cross your electrical wiring with your signal wiring. This can cause distortion and interference.

Follow these instructions to prevent distortion when the compressor starts:

- The unit must be connected to the main outlet. Normally, the power supply must have a low output impedance of 32 ohms.
- No other equipment should be connected to the same power circuit.
- The unit's power information can be found on the rating sticker on the product.

TAKE NOTE OF FUSE SPECIFICATIONS

The air conditioner's circuit board (PCB) is designed with a fuse to provide overcurrent protection. The specifications of the fuse are printed on the circuit board, such as: T3.15A/250VAC, T5A/250VAC, etc.

Outdoor Unit Wiring

WARNING

Before performing any electrical or wiring work, turn off the main power to the system.

1. Prepare the cable for connection
 - a. You must first choose the right cable size before preparing it for connection. Be sure to use H07RN-F cables.

Table 8.1: Minimum Cross-Sectional Area of Power and Signal Cables North America

Rated Current of Appliance (A)	AWG
≤ 7	18
7 - 13	16
13 - 18	14
18 - 25	12
25 - 30	10

Table 8.2: Other Regions

Rated Current of Appliance (A)	Nominal Cross-Sectional Area (mm ²)
≤ 6	0.75
6 - 10	1
10 - 16	1.5
16 - 25	2.5
25 - 32	4
32 - 45	6

- b. Using wire strippers, strip the rubber jacket from both ends of signal cable to reveal about 15cm (~6") of the wires inside.
- c. Strip the insulation from the ends of the wires.
- d. Using a wire crimper, crimp u-lugs onto the ends of the wires.

NOTE: When connecting the wires, please strictly follow the wiring diagram (found inside the electrical box cover).

2. Remove the electrical cover of the outdoor unit. If there is no cover on the outdoor unit, disassemble the bolts from the maintenance board, and remove the protection board. (See Fig. 8.1, 8.2)




Fig. 8.1

3. Connect the u-lugs to the terminals. Match the wire colors/labels with the labels on the terminal block, and firmly screw the u-lug of each wire to its corresponding terminal.
4. Clamp down the cable with designated cable clamps.
5. Insulate unused wires with electrical tape. Keep them away from any electrical or metal parts.
6. Reinstall the cover of the electrical control box.

Indoor Unit Wiring

1. Prepare the cable for connection
 - a. Using wire strippers, strip the rubber jacket from both ends of signal cable to reveal about 15cm (~6") of wire inside.
 - b. Strip the insulation from the ends of the wires.
 - c. Using wire crimper, crimp the u-lugs onto the ends of the wires.

2. Open the front panel of the indoor unit. Using a screwdriver, remove the cover of the electric control box on your indoor unit.
3. Thread the power cable and the signal cable through the wire outlet.




Fig. 8.3

4. Connect the u-lugs to the terminals. Match the wire colors/labels with the labels on the terminal block, and firmly screw the u-lug of each wire to its corresponding terminal. Refer to the Serial Number and Wiring Diagram located on the cover of the electric control box.





Fig. 8.4

! CAUTION

- When connecting the wires, please follow the wiring diagram strictly.
- The refrigerant circuit can become very hot. Keep the interconnection cable away from the copper tube.

5. Clamp down cable with the designated cable clamp to secure it in place. The cable should not be loose, and should not pull on the u-lugs.
6. Reinstall the electrical box cover and the front panel of the indoor unit.



Caution: Systems are precharged with refrigerant (entire amount necessary for the system set has been charged into the outdoor section). The line sets and the indoor units are not charged, and must be evacuated prior to releasing the refrigerant from the outdoor unit to the rest of the system. Do NOT open the valves of the 2 service ports on your outdoor unit until the air evacuation is completed successfully, and the system passes leak checks. BOTH of those Service valves MUST BE OPENED to release the refrigerant before turning the system ON. Operating the system with service valves closed will result in compressor damage.

Preparations and Precautions

Air and foreign matter in the refrigerant circuit can cause abnormal rises in pressure, which can damage the air conditioner, reduce its efficiency, and cause injury. Use a vacuum pump and manifold gauge to evacuate the line set and the indoor unit, removing any non-condensable gas and moisture from the system.

Evacuation should be performed upon initial installation, and when unit is relocated.

BEFORE PERFORMING EVACUATION

- Check to make sure that both LIQUID SIDE and GAS SIDE pipes between the indoor and outdoor units are connected properly, in accordance with the Refrigerant Piping Connection section of this manual.
- Check to make sure all wiring is connected properly.

Before using the manifold gauge and vacuum pump, read their operation manuals to familiarize yourself with how to use them properly.

Evacuation Instructions





Fig. 6.1

1. Connect the blue (low side) hose of the manifold gauge to the service port on the outdoor unit's GAS SIDE valve (use a 1/4" to 5/16" port adapter if needed, which is sold separately)
2. Connect the yellow (middle or common) hose from the manifold gauge to the vacuum pump.

3. Open the BLUE (Low Pressure) valve of Manifold Gauge. Keep the RED (High Pressure) valve closed.
4. Turn the vacuum pump ON to start evacuating the air from the line set and indoor unit circuits.
5. Run the vacuum pump for at least 15 minutes, or until the Low Pressure Gauge reads -76cmHG (-100 kPa or -30 In Hg). (Negative value)
6. Close the Blue (Low Pressure) valve of Manifold Gauge, then turn the vacuum pump OFF.
7. Wait for 5 minutes, then check that there has been no rise in Low Pressure Gauge reading.
8. If there is a rise (Vacuum Loss), refer to the Gas Leak Check section for information on how to check for leaks. If there is no change in vacuum reading, unscrew the cap from the LIQUID Side Service Valve (Fig. 6.2)
9. Insert a hexagonal wrench into the service valve (LIQUID Side Valve), and open the valve by turning the wrench in a 1/4 counterclockwise turn. Listen for the sound of gas exiting the system, then close the valve after 5 seconds.
10. The Low Pressure Gauge should now show a positive pressure value (Above Zero). Watch the Pressure Gauge for a few minutes, to make sure that there is no drop in the pressure value (indicating a leak)



11. Using a hexagonal wrench, fully open both the LIQUID side and GAS side Service Valves.
12. Remove the charging hose from the service port.
13. Tighten valve caps on all three valves (service port, liquid side, gas side) by hand. Then, tighten it further using a torque wrench, if needed.

! OPEN VALVE STEMS GENTLY

When opening valve stems, turn the hexagonal wrench until it seats against the stopper. Do not try to force the valve to open further.

Note on Adding Refrigerant

Some systems require additional charging depending on pipe lengths. The pipe length varies according to locations of the indoor and outdoor units. The system has been factory charged with sufficient R410a refrigerant for the standard pipe length of 5m (~16'). The additional refrigerant to be charged can be calculated using the following formula. This is necessary only if the length exceeds 7.5m (25 feet).

ADDITIONAL REFRIGERANT PER PIPE LENGTH

Connective Pipe Length (m)	Air Purging Method	Additional Refrigerant	
≤ Standard pipe length	Vacuum Pump	N/A	
> Standard pipe length (5m/~16')	Vacuum Pump	Liquid Side: Ø 6.35 (ø 1/4") Gas side either Ø 9.52 (ø 3/8") or Ø 12.7 (ø 1/2") Add for lengths beyond 5m (16 feet) (Per additional meter) x 15g /m (Per additional foot) x 0.16 oz/ft	Liquid Side: Ø 9.52 (ø 3/8") Gas side either Ø 15.87 (ø 5/8") or Ø 19.05 (ø 3/4") Add for lengths beyond 5m (16 feet) (Per additional meter) x 30 g/m (Per additional foot) x 0.32 oz/ft

! CAUTION

DO NOT mix refrigerant types. Be sure to use only the same type of refrigerant (R410a).

! CAUTION

DO NOT place the panel facedown onto the floor, against a wall, or on uneven surfaces.

Step 1: Remove the front grille.

1. Push both of the tabs towards the middle simultaneously to unlock the hook on the grille.
2. Hold the grille at a 45° angle, lift it up slightly, and detach it from the main body.




Fig. 10.1

Step 2: Remove the installation covers at the four corners by sliding them outwards.




Fig. 10.2

Step 3: Install the Panel

Align the front panel to the main body, taking into account the position of the piping and drain sides. Hang the four latches of the decorative panel to the hooks of the indoor unit. Tighten the panel hook screws evenly at the four corners. (See Fig. 10.3)

NOTE: Tighten the screws until the thickness of the sponge between the main body and the panel reduces to 4-6mm (0.2-0.3"). The edge of the panel should be in good contact with the ceiling.

Adjust the panel by turning it to the arrowed direction shown in Fig 10.3, so that the ceiling opening is completely covered.




Fig. 10.3

1. Connect the two louver motor connectors to the corresponding wires in the control box.




Fig. 10.4

2. Remove foam stops from inside the fan.
3. Attach the side of the front grille to the panel.
4. Connect the display panel cable to the corresponding wire on the main body.




Fig. 10.5

! CAUTION

Failure to tighten screws can cause water leakage.

5. Close the front grille.
6. Fasten the installation covers on all four corners by pushing them inwards. (See Fig. 10.6)




Fig. 10.6

NOTE: If the height of the indoor unit needs to be adjusted, you can do so through the openings at the panel's four corners. Make sure that the internal wiring and drainpipe are not affected by this adjustment.




Fig. 10.7

! CAUTION

If the unit is not hung correctly and a gap is present, the unit's height must be adjusted to ensure proper function. The unit's height can be adjusted by loosening the upper nut, and adjusting the lower nut.




Fig. 10.8

Before Test Run

A test run must be performed after the entire system has been completely installed. Confirm the following points before performing the test:

- a) The indoor and outdoor units are properly installed.
- b) Piping and wiring are properly connected.
- c) Ensure that there are no obstacles near the inlet and outlet of the unit that might cause poor performance, or product malfunction.
- d) The refrigeration system does not leak.
- e) The drainage system is unimpeded and is draining to a safe location.
- f) The heating insulation is properly installed.
- g) The grounding wires are properly connected.
- h) The length of the piping and the added refrigerant stow capacity have been recorded.
- i) The power voltage is the correct voltage for the air conditioner.

CAUTION

Failure to perform the test run may result in unit damage, property damage or personal injury.

Test Run Instructions

1. Open both the liquid and gas stop valves.
2. Turn on the main power switch, and allow the unit to warm up.
3. Set the air conditioner to COOL mode.
4. For the Indoor Unit:
 - a. Ensure the remote control and its buttons are working properly.
 - b. Ensure the louvers move properly, and can be changed using the remote control.
 - c. Double check to see if the room temperature is being registered correctly.
 - d. Ensure the indicators on the remote control and the display panel on the indoor unit work properly.
 - e. Ensure the manual buttons on the indoor unit work properly.

- f. Check to see that the drainage system is unimpeded, and is draining smoothly.
 - g. Ensure there is no vibration or abnormal noise during operation.
5. For the Outdoor Unit:
 - a. Check to see if the refrigeration system is leaking.
 - b. Make sure there is no vibration or abnormal noise during operation.
 - c. Ensure the wind, noise, and water generated by the unit do not disturb your neighbors, or pose a safety hazard.
 6. Drainage Test:
 - a. Ensure the drainpipe flows smoothly. New buildings should perform this test before finishing the ceiling.
 - b. Remove the test cover. Add 2,000ml of water to the tank through the attached tube.
 - c. Turn on the main power switch, and run the air conditioner in COOL mode.
 - d. Listen to the sound of the drain pump to see if it makes any unusual noises.
 - e. Check to see that the water is discharged. It may take up to one minute before the unit begins to drain, depending on the drainpipe.
 - f. Make sure that there are no leaks in any of the piping.
 - g. Stop the air conditioner. Turn off the main power switch, and reinstall the test cover.

NOTE: If the unit malfunctions, or does not operate according to your expectations, please refer to the Troubleshooting section of the Owner's Manual before calling customer service.

QSQ4I-026AEN

The design and specifications are subject to change without prior notice for product improvement. Consult with the sales agency or manufacturer for details.



is a registered trademark of Parker Davis HVAC International, Inc.

Parker Davis HVAC International, Inc.

2250 NW 102 Place, Doral, FL 33172 - USA

Tel : (305) 513-4488

Fax : (305) 513-4499

email : info@pd-hvac.com

Website: www.pd-hvac.com

16122500000189

20170301